



Bestell-Nr.:	Visuell	Beschreibung	Bezeichnung
60308 60309	Fallrohr-Fertigkonsole fvz 	= F SP 30-30-2 250 mm lang = F SP 50-40-3 250 mm lang	F FRK 0 F FRK 1
60310 60311 60312 60313 60314	Fallrohr-Fertigkonsole 250 mm lang 	= F SP 30-30-2 z bei Rohr DN 50 = F SP 30-30-2 z bei Rohr DN 70/80 = F SP 30-30-2 z bei Rohr DN 100 = F SP 30-30-2 z bei Rohr DN 125 = F SP 30-30-2 z bei Rohr DN 150	F FRK 50 z F FRK 70/80 z F FRK 100 z F FRK 125 z F FRK 150 z
60315	Unterstützungshalter fvz 	= F SP 50 60-40-4 LL 14x26mm	F UH 50-1
60316	Unterstützungshalter fvz 	= F SP 50 -40-3 LL 14x26mm	F UH 50-2
60317	Unterstützungshalter fvz 	= F SP 60 -40-4 LL 14x26mm	F UH 50-3
60318	Unterstützungplatte fvz 	= F K 50-40-350; F K 50-40-550	F USP 1
60319 60320 60321	Unterstützungslasche fvz 	= F SP 50 60-40-35-4 Loch 9 mm = F SP 50 60-40-35-4 Loch 14 mm = F SP 50 60-40-35-4 Loch 17 mm	F UL 50-08 F UL 50-12 F UL 50-16
60322	Verbindungs-lasche fvz 190 mm	= SP 50 60-40-4 Loch 14 mm	F VL 50
60323	Lochplatte fvz	120-75-5 Loch 13 mm	F LP 1
60324	Bodenhalter fvz 	= F SP 50-50 LL 14x26 mm 160-70-10mm	F BH 50-50
60325	Bodenhalter, 90 Grad, fvz 	= F SP 50-50 LL 14x26 mm 160-70-10mm	F BH 50-50 v



EDELSTAHL					
Befestigungsteile V4A					
70605 70606 70607 70608 70609	Fertigkonsole mit Abstützung V4A 	= F SP 50-40-3 = F SP 50-40-3 = F SP 50-40-3 = F SP 50-40-3 = F SP 50-40-3	550 mm lang 650 mm lang 750 mm lang 850 mm lang 1000 mm lang	F KUH50-40-550 V4A F KUH 50-40-650 V4A F KUH 50-40-750 V4A F KUH 50-40-850 V4A F KUH 50-40-1000 4A	
70610 70611	Fallrohr-Fertigkonsole V4A 	= F SP 30-30-2 = F SP 50-40-3	250 mm lang 250 mm lang	F FRK 0 V4A F FRK 1 V4A	
70612 70613 70614 70615 70616	Fallrohr-Fertigkonsole 250 mm lang 	= F SP 30-30-2 z = F SP 30-30-2 z = F SP 30-30-2 z = F SP 30-30-2 z = F SP 30-30-2 z	bei Rohr DN 50 bei Rohr DN 70/80 bei Rohr DN 100 bei Rohr DN 125 bei Rohr DN 150	F FRK 50 z V4A F FRK 70/80 z V4A F FRK 100 z V4A F FRK 125 z V4A F FRK 150 z V4A	
70617	Unterstützungshalter V4A 	= F SP 50 60-40-4	LL 14x26mm	F UH 50-1 V4A	
70618	Unterstützungshalter V4A 	= F SP 50 -40-3	LL 14x26mm	F UH 50-2 V4A	
70619	Unterstützungshalter V4A 	= F SP 60 -40-4	LL 14x26mm	F UH 50-3 V4A	
70620	Unterstützungsplatte V4A 	= F K 50-40-350; F K 50-40-550		F USP 1 V4A	
70621 70622 70623	Unterstützungslasche V4A 	= F SP 50 60-40-35-4 = F SP 50 60-40-35-4 = F SP 50 60-40-35-4	Loch 9 mm Loch 14 mm Loch 17 mm	F UL 50-08 V4A F UL 50-12 V4A F UL 50-16 V4A	